


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

## Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.  
**Heat and UV exposure will warp and fade components.**
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

## Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly



Spline Connection



Extrusion &amp; Lock Connection



Engaged Lock



# WARNING



DO NOT USE POWER TOOLS



LADDERS OR LIFTS  
MAY BE REQUIRED




ALL CONNECTIONS MUST  
BE TIGHTLY SECURED


## Straight Connection

When assembling frame, first attach all **straight connectors**, then attach **corner connectors**.

- 1) Place extrusions end-to-end.
- 2) Loosen all knobs, then slide **straight connector** across the seam of extrusions.
- 3) Tighten all knobs to secure connection.



Slide connector across seam of extrusions.  
Tighten all knobs.



All knobs must be tightened securely to ensure a proper connection.

## Disassembly

- 1) Loosen all knobs.
- 2) Slide connectors off of one extrusion.
- 3) Tighten knobs to prevent loss during packing & shipping.



Keep straight connectors in groove of extrusion. Do not remove connectors during disassembly.

## Corner Connection


- 1) Loosen knobs, then slide vertical extrusions onto **corner connectors** of **lower** horizontal extrusion.
- 2) Slide **corner connectors** of **upper** horizontal extrusion into grooves of vertical extrusions.
- 3) Tighten all knobs to secure connection.

## Disassembly

- 1) Loosen knobs on vertical extrusions.
- 2) Slide the vertical extrusions off of **corner connectors** on lower and upper horizontal extrusions.



Adjust connectors if necessary to prevent gaps in connection.




COMPLETED ASSEMBLY


All knobs must be tightened securely to ensure a proper connection.



TSP46 Profile



It is important to first insert graphic into each alternate corner then to the sides of the frame. If this is not done, graphic will not fit into the frame correctly.



#### Step 1

Insert corner A. Turn edge of graphic so silicon welt is perpendicular to face of graphic. Insert narrow side of welt with fabric to outside into the channel. Repeat for other side of this corner.



#### Step 2

Repeat Step 1 for opposite corner C, then insert corner B, followed by corner D, to complete the installation of the corners.



#### Step 3






Once all corners are inserted, press one silicon edge into channel from corners and work toward the center. Make sure welt is fully inserted into channel. Continue until all sides are done. Smooth out edges of graphic.

#### Graphic Removal





To remove the graphic from the frame, locate the fabric pull tab. Gently pull up on the tab to remove the fabric.


Label:	Qty:	Size:	Description:
A1)	1	45" 45/90 miter	TSP 46 Extrusion w/ A10 Brackets
A2)	1	45" 90/45 miter	TSP 46 Extrusion w/ holes for baseplate and A10 Brackets
A3)	1	45" 45/90 miter	TSP 46 Extrusion
A4)	1	45" 90/45 miter	TSP 46 Extrusion
A5)	1	45" 45/90 miter	TSP 46 Extrusion w/ holes for baseplate and A10 Brackets
A6)	1	45" 90/45 miter	TSP 46 Extrusion w/ A10 Brackets
A7)	1	45" 45/90 miter	TSP 46 Extrusion
A8)	1	45" 90/45 miter	TSP 46 Extrusion
A9)	4	43.209"	Z45 Extrusion
A10)	1	22"	Z140 Extrusion with Standoff Barrels
A11)	2	6.7" x 19.2"	Boomerang Base




Item	Qty.	Description
1	1	38" h Gravitee Corner Post w/ Door Attachment
2	1	14.125" w x 38" h Gravitee Panel Frame
3	1	38" h Gravitee Corner Post
4	1	19" w x 38" h Gravitee Panel Frame
5	1	19" w x 38" h Gravitee Panel Frame
6	1	38" h Gravitee Corner Post
7	1	14.125" w x 38" h Gravitee Panel Frame
8	1	38" h Gravitee Corner Post w/ Door Attachment
9/9A	1/1	37.0945" w Z45 Horizontal Extrusion
10	1	34.4173" h Z45 Vertical Extrusion




Plan View





Back Side




BACK SIDE






Back View



Front View



## Steps:

- 1) Wrap **SEG Graphic** around front & sides of counter as shown.
- 2) Attach internal Shelf Supports using **Velcro**; place Internal Shelf.
- 3) Place Counter Top on assembly & secure in place.

